



How to Setup the Symbol LS2208 USB Barcode Scanner

Only use this guide to setup the Symbol LS2208 USB Barcode Scanner for the first time. This device is used in the order entry mode of RepTime where you have to select catalog items. Follow the steps from 1 – 6 and scan all the barcodes one after the other. Do not skip any. **To test if the set up worked**, open up Notepad.exe Program on a computer and scan a few items; the results should have a pipe character '|' in front, followed by the item number (e.g. |D45F450). If the set up did not work, please scan the bar code at the bottom of this guide to reset the scanner to the default settings, and follow the steps again.

Note that you must setup the Bar Code Scanner with these instructions for it to work properly with RepTime.

Barcode Scanner Programming Instructions...

Step 1) Start Here with Scan Options



Step 2) Data Transmission Format



Step 3) Prefix Values



Step 4) Prefix to Program Pipe '|'



Step 5) Suffix Values



Step 6) Program Enter as Suffix



To RESET the Scanner to Factory Defaults. Scan the barcode below and begin Step 1



This information will help streamline the process. Thank you for your cooperation.
Feel free to contact RepTime if you have any questions at 214-746-3671 or support@reptime.com.