



RepTime Showroom - Things To Know...

How to Setup the Symbol LS2208 USB Bar Code Scanner

Please only use this guide to setup the Symbol LS2208 USB Bar Code Scanner for the first time. This device is used in the order entry mode of RepTime where you have to select catalog items. Follow the steps from 1 – 6 and scan all the barcodes one after the other. Do not skip any.

To test if the set up worked, open up **Notepad.exe Program** on a computer and scan a few items; the results should have a pipe character '|' in front, followed by the item number (e.g. |D45F450). If the set up did not work, please scan the bar code at the bottom of this guide to reset the scanner to the default settings, and follow the steps again.

Note that you must setup the Bar Code Scanner with these instructions for it to work properly with RepTime.

Barcode Scanner Programming Instructions...

Step 1) Start Here with Scan Options:



Step 2) Data Transmission Format:



Step 3) Prefix Values:



Step 4) Prefix to Program Pipe '|':



Step 5) Suffix Values:



Step 6) Program Enter as Suffix:



To RESET the Scanner to Factory Defaults. Scan the barcode below and begin Step 1.



This information will help streamline the process. Thank you for your cooperation. Feel free to contact RepTime if you have any questions at 214-746-3671 or support@reptime.com.